

## MAGNETIC PICK-UP DIP SWITCH CHART

NUMBER OF TEETH ON FLYWHEEL	CLOSE SWITCH
80	-
81	7,8
82	6,7,8
83	5,7,9
84	5,6,7,10
85	3,7
86	3,6,10
87	3,6,7,8,9
88	3,5,7,8
89	3,5,6,7
90	3,4,6,8
91	3,4,5
92	3,4,5,7,8
93	2,7
94	2,6
95	2,6,7,8
96	2,5,8
97	2,4
98	2,4,8,9,10
99	2,3,9
100	2,3,7,8,10
101	2,3,6,8
102	2,3,6,7,8,9
103	2,3,5,7,10
104	2,3,4
105	2,3,4,7,9
106	2,3,4,6,10
107	2,3,4,6,7,9
108	2,3,4,5,10
109	2,3,4,5,7,9
110	2,3,4,5,6,10
111	2,3,4,5,6,7,9
112	1,6,10
113	1,6,7,10
114	1,5
115	1,5,7,10
116	1,5,7,8,9
117	1,4,7
118	1,4,7,8,10
119	1,3,9

NUMBER OF TEETH ON FLYWHEEL	CLOSE SWITCH
120	1,3,7,9
121	1,3,7,8,9,10
122	1,3,6,7
123	1,3,6,7,8,10
124	1,3,5,9
125	1,3,5,7,9
126	1,3,4
127	1,3,4,7
128	1,3,4,7,8
129	1,3,4,6,10
130	1,3,4,6,7
131	1,3,4,6,7,8
132	1,3,4,5,10
133	1,3,4,5,7
134	1,3,4,5,7,8
135	1,3,4,5,6,10
136	1,3,4,5,6,7
137	1,3,4,5,6,7,8
138	1,2,6,10
139	1,2,6,8
140	1,2,6,7,8
141	1,2,6,7,8,9,10
142	1,2,5,9
143	1,2,5,7,10
144	1,2,5,7,8,10
145	1,2,5,6,10
146	1,2,5,6,8,10
147	1,2,5,6,7,9,10
148	1,2,5,6,7,8,9
149	1,2,4,6,9
150	1,2,4,6,8,9
151	1,2,4,6,7,9,10
152	1,2,4,6,7,8,9,10
153	1,2,4,5,9
154	1,2,4,5,8,9
155	1,2,4,5,7,9,10
156	1,2,4,5,7,8,9,10
157	1,2,4,5,6,9
158	1,2,4,5,6,8,10
159	1,2,4,5,6,7,9,10

## ALTERNATOR INPUT DIP SWITCH CHART

NUMBER OF ENGINE CYLINDERS OR ALTERNATOR POLES	OPEN SWITCH
4	1,2
6	2,3
8	2
10	4,5
12	4
20	6

