



WARNING

Improper installation may damage the controller and/or cause injury to the installer. If you have installation questions, please contact the factory. Disconnect battery cables before installing the controller.

Installation

Mount the controller using the two holes provided.

Use appropriate type of fastener for mounting. Fasteners not provided with controller. Mounting holes for 6mm or 1/4" Dia fastener.

Maintenance

Periodically check and torque all hardware per mounting specifications.

Wire Connections

